



HIGH EFFICIENCY GEARS SYNTHESIS BY AVOID THE INTERFERENCES

*Florian Ion Tiberiu Petrescu
Bucharest Polytechnic University, Romania
E-mail: petrescuflorian@yahoo.com*

*Relly Victoria Virgil Petrescu
Bucharest Polytechnic University, Romania
E-mail: petrescuvictoria@yahoo.com*

Submission: 27/09/2013

Revision: 19/10/2013

Accept: 20/10/2013

ABSTRACT

The paper presents an original method to determine the efficiency of the gear, the forces of the gearing, the velocities and the powers. It is analyzing the influence of a few parameters concerning gear efficiency. These parameters are: z_1 - the number of teeth for the primary wheel of gear; z_2 - the number of teeth of the secondary wheel of gear; α_0 - the normal pressure angle on the divided circle; β - the inclination angle. With the relations presented in this paper, it can synthesize the gear's mechanisms. Today, the gears are present everywhere, in the mechanical's world (In vehicle's industries, in electronics and electro-technique equipments, in energetically industries, etc). Optimizing this mechanism (the gears mechanism), we can improve the functionality of the transmissions with gears. At the gear mechanisms an important problem is the interference of the teeth. To avoid the interference between teeth, we must know the minimum number of teeth of the driving wheel, in function of the pressure angle (normal on the pitch circle, α_0), in function of the tooth inclination angle (β), and in function of the transmission ratio (i).

Keywords: gears; gear efficiency; forces; velocities; powers; number of teeth; avoid the interference



1. INTRODUCTION

Gears, broke today in all fields. They have the advantage of working with very high efficiency. Additionally gears can transmit large loads. Regardless of their size, gear must be synthesized carefully considering the specific conditions. This paper tries to present the main conditions that must be met for correct synthesis of a gear (PETRESCU, 2012; PETRESCU; PETRESCU, 2002; PETRESCU; PETRESCU, 2003; PETRESCU; PETRESCU; POPESCU, 2007).

Top of the use of sprocket mechanisms must be sought in ancient Egypt with at least a thousand years before Christ. Here were used for the first time, transmissions wheeled "spurred" to irrigate crops and worm gears to the cotton processing (LIN C., 2011; LEI X., 2011). With 230 years BC, in the city of Alexandria in Egypt, they have been used the wheel with more levers and gear rack. Such gears have been constructed and used beginning from the earliest times, to the top for lifting the heavy anchors of vessels and for claim catapults used on the battlefields. Then, they were introduced in cars with wind and water (as a reducing or multiplying at the pump from windmills or water), (see Figure 1).




Figure 1: Transmissions wheeled "spurred" to irrigate crops and worm gears to the cotton processing

The Antikythera Mechanism is the name given to an astronomical calculating device, measuring about 32 by 16 by 10 cm, which was discovered in 1900 in a sunken ship just off the coast of Antikythera, an island between Crete and the Greek mainland. Several kinds of evidence point incontrovertibly to around 80 B.C. for the date of the shipwreck. The device, made of bronze gears fitted in a wooden case, was crushed in the wreck, and parts of the faces were lost, "the rest then being coated with a hard calcareous deposit at the same time as the metal corroded away to a thin core coated with hard metallic salts preserving much of the former shape of the bronze" during the almost 2000 years it lay submerged. (See Antikythera 1, in Figure 2).




Figure 2: The Antikythera Mechanism is the name given to an astronomical calculating device

Modern adventure began with the gear wheel spurred of Leonardo da Vinci, in the fifteenth century. He founded the new kinematics and dynamics stating inter alia the principle of superposition of independent movements (Figure 3).




Figure 3: The modern adventure began with the gear wheel spurred of Leonardo da Vinci, in the fifteenth century

Benz had engine with transmissions sprocket gearing and Gear chain (patented after 1882, Figure 4), but the first gearing patent (the drawings of a patent first gear transmission) and of gearing wheels with chain was made in 1870 by the British Starley & Hillman (REY, 2013).





Figure 4: The Benz patent



After 1912, in Cleveland (USA), begin to produce industrial specialized wheels and gears (cylindrical, worm, conical, with straight teeth, inclined or curved; see Figure 5).



After 1912, in Cleveland (USA), begin to produce industrial specialized wheels and gears (cylindrical, worm, conical, with straight teeth, inclined or curved).

Figure 5: In Cleveland, after 1912 begin to produce industrial specialized wheels

Today, the gears are present everywhere, in the mechanical's world (In vehicle's industries, in electronics and electro-technique equipment's, in energetically industries, etc.; Figure 6).



Figure 6. Gearing today

2. GEARS SYNTHESIS

The calculating relations (PETRESCU, 2012), are the next (2.1-2.21).

2.1. Determining the momentary dynamic (mechanical) efficiency, the forces of the gearing, and the velocities

The forces, velocities, powers and efficiency can be obtained with the relationships 2.1-2.6; the forces from gearing may be seen in the Figure 7.




Figure 7: The forces and the velocities of the gearing

$$\begin{cases} F_{\tau} = F_m \cdot \cos \alpha_1 \\ F_{\psi} = F_m \cdot \sin \alpha_1 \\ v_2 = v_1 \cdot \cos \alpha_1 \\ v_{12} = v_1 \cdot \sin \alpha_1 \\ \bar{F}_m = \bar{F}_{\tau} + \bar{F}_{\psi} \\ \bar{v}_1 = \bar{v}_2 + \bar{v}_{12} \end{cases} \quad (2.1)$$

with: F_m - the motive force (the driving force);

F_{τ} - the transmitted force (the useful force);

F_{ψ} - the slide force (the lost force);



v_1 - the velocity of element 1, or the speed of wheel 1 (the driving wheel);

v_2 - the velocity of element 2, or the speed of wheel 2 (the driven wheel);

v_{12} - the relative speed of the wheel 1 in relation with the wheel 2 (this is a sliding speed).

The consumed power (in this case the driving power):

$$P_c \equiv P_m = F_m \cdot v_1 \quad (2.2)$$

The useful power (the transmitted power from the profile 1 to the profile 2) will be written:

$$P_u \equiv P_\tau = F_\tau \cdot v_2 = F_m \cdot v_1 \cdot \cos^2 \alpha_1 \quad (2.3)$$

The lost power will be written:

$$P_\psi = F_\psi \cdot v_{12} = F_m \cdot v_1 \cdot \sin^2 \alpha_1 \quad (2.4)$$

The momentary efficiency of couple will be calculated directly with the next relation:

$$\begin{cases} \eta_i = \frac{P_u}{P_c} \equiv \frac{P_\tau}{P_m} = \frac{F_m \cdot v_1 \cdot \cos^2 \alpha_1}{F_m \cdot v_1} \\ \eta_i = \cos^2 \alpha_1 \end{cases} \quad (2.5)$$

The momentary losing coefficient (PETRESCU, 2012), will be written:

$$\begin{cases} \psi_i = \frac{P_\psi}{P_m} = \frac{F_m \cdot v_1 \cdot \sin^2 \alpha_1}{F_m \cdot v_1} = \sin^2 \alpha_1 \\ \eta_i + \psi_i = \cos^2 \alpha_1 + \sin^2 \alpha_1 = 1 \end{cases} \quad (2.6)$$

It can easily see that the sum of the momentary efficiency and the momentary losing coefficient is 1.

Now, one can determine the geometrical elements of gear. These elements will be used in determining the couple efficiency, η .

2.2. The geometrical elements of the gear

We can determine the next geometrical elements of the external gear, (for the right teeth, $\beta=0$), (PETRESCU, 2012).

The radius of the basic circle of the wheel 1 (of the driving wheel), (2.7).

$$r_{b1} = \frac{1}{2} \cdot m \cdot z_1 \cdot \cos \alpha_0 \quad (2.7)$$

The radius of the outside circle of wheel 1 (2.8):



$$r_{a1} = \frac{1}{2} \cdot (m \cdot z_1 + 2 \cdot m) = \frac{m}{2} \cdot (z_1 + 2) \quad (2.8)$$

It determines now the maximum pressure angle of the gear (2.9):

$$\cos \alpha_{1M} = \frac{r_{b1}}{r_{a1}} = \frac{\frac{1}{2} \cdot m \cdot z_1 \cdot \cos \alpha_0}{\frac{1}{2} \cdot m \cdot (z_1 + 2)} = \frac{z_1 \cdot \cos \alpha_0}{z_1 + 2} \quad (2.9)$$

And now one determines the same parameters for the wheel 2, the radius of basic circle (2.10) and the radius of the outside circle (2.11) for the wheel 2:

$$r_{b2} = \frac{1}{2} \cdot m \cdot z_2 \cdot \cos \alpha_0 \quad (2.10)$$

$$r_{a2} = \frac{m}{2} \cdot (z_2 + 2) \quad (2.11)$$

Now it can determine the minimum pressure angle of the external gear (2.12, 2.13):

$$\left\{ \begin{aligned} \operatorname{tg} \alpha_{1m} &= \frac{N}{r_{b1}} \\ N &= (r_{b1} + r_{b2}) \cdot \operatorname{tg} \alpha_0 - \sqrt{r_{a2}^2 - r_{b2}^2} = \\ &= \frac{1}{2} \cdot m \cdot (z_1 + z_2) \cdot \sin \alpha_0 - \\ &- \frac{m}{2} \cdot \sqrt{(z_2 + 2)^2 - z_2^2 \cdot \cos^2 \alpha_0} = \\ &= \frac{m}{2} \cdot [(z_1 + z_2) \cdot \sin \alpha_0 - \\ &- \sqrt{z_2^2 \cdot \sin^2 \alpha_0 + 4 \cdot z_2 + 4}] \end{aligned} \right. \quad (2.12)$$

$$\operatorname{tg} \alpha_{1m} = [(z_1 + z_2) \cdot \sin \alpha_0 - \sqrt{z_2^2 \cdot \sin^2 \alpha_0 + 4 \cdot z_2 + 4}] / (z_1 \cdot \cos \alpha_0) \quad (2.13)$$

Now we can determine, for the external gear, the minimum (2.13) and the maximum (2.9) pressure angle for the right teeth. For the external gear with bended teeth ($\beta \neq 0$) it uses the relations (2.14, 2.15 and 2.16):

$$\operatorname{tg} \alpha_t = \frac{\operatorname{tg} \alpha_0}{\cos \beta} \quad (2.14)$$

$$\operatorname{tg} \alpha_{1m} = [(z_1 + z_2) \cdot \frac{\sin \alpha_t}{\cos \beta} - \sqrt{z_2^2 \cdot \frac{\sin^2 \alpha_t}{\cos^2 \beta} + 4 \cdot \frac{z_2}{\cos \beta} + 4}] \cdot \frac{\cos \beta}{z_1 \cdot \cos \alpha_t} \quad (2.15)$$



$$\cos \alpha_{1M} = \frac{\frac{z_1 \cdot \cos \alpha_t}{\cos \beta}}{\frac{z_1}{\cos \beta} + 2} \quad (2.16)$$

For the internal gear with bended teeth ($\beta \neq 0$) it uses the relations (2.14 with 2.17, 2.18-A, or with 2.19, 2.20-B):

A. When the driving wheel 1, has external teeth:

$$tg \alpha_{1m} = [(z_1 - z_2) \cdot \frac{\sin \alpha_t}{\cos \beta} + \sqrt{z_2^2 \cdot \frac{\sin^2 \alpha_t}{\cos^2 \beta} - 4 \cdot \frac{z_2}{\cos \beta} + 4}] \cdot \frac{\cos \beta}{z_1 \cdot \cos \alpha_t} \quad (2.17)$$

$$\cos \alpha_{1M} = \frac{\frac{z_1 \cdot \cos \alpha_t}{\cos \beta}}{\frac{z_1}{\cos \beta} + 2} \quad (2.18)$$

B. When the driving wheel 1, have internal teeth:

$$tg \alpha_{1M} = [(z_1 - z_2) \cdot \frac{\sin \alpha_t}{\cos \beta} + \sqrt{z_2^2 \cdot \frac{\sin^2 \alpha_t}{\cos^2 \beta} + 4 \cdot \frac{z_2}{\cos \beta} + 4}] \cdot \frac{\cos \beta}{z_1 \cdot \cos \alpha_t} \quad (2.19)$$

$$\cos \alpha_{1m} = \frac{\frac{z_1 \cdot \cos \alpha_t}{\cos \beta}}{\frac{z_1}{\cos \beta} - 2} \quad (2.20)$$

2.3. Determining the efficiency of the gear

The efficiency of the gear will be calculated through the integration of momentary efficiency on all sections of gearing movement, namely from the minimum pressure angle to the maximum pressure angle, the relation (2.21), (PETRESCU, 2012).

$$\begin{aligned} \eta &= \frac{1}{\Delta \alpha} \cdot \int_{\alpha_m}^{\alpha_M} \eta_i \cdot d\alpha = \frac{1}{\Delta \alpha} \int_{\alpha_m}^{\alpha_M} \cos^2 \alpha \cdot d\alpha = \frac{1}{2 \cdot \Delta \alpha} \cdot \left[\frac{1}{2} \cdot \sin(2 \cdot \alpha) + \alpha \right]_{\alpha_m}^{\alpha_M} = \\ &= \frac{1}{2 \cdot \Delta \alpha} \left[\frac{\sin(2\alpha_M) - \sin(2\alpha_m)}{2} + \Delta \alpha \right] = \frac{\sin(2 \cdot \alpha_M) - \sin(2 \cdot \alpha_m)}{4 \cdot (\alpha_M - \alpha_m)} + 0.5 \end{aligned} \quad (2.21)$$

2.4. External and internal gearing

Exterior gearing are the most common, not because it would be best but because they are easier to designed and constructed (Figure 8). Interior gearing may be more efficient and more reliable when they are projected properly (Figure 9).






Figure 8. An external gearing




Figure 9. An internal gearing

To an external gearing contact between profiles shall only be made to a single point, while at the internal gearing the contact between profiles is by winding each other (see the Figure 10 and (PETRESCU, 2012)).




Figure 10. Contact between profiles

3. GEARS SYNTHESIS BY AVOID THE INTERFERENCES

In order to avoid interference phenomenon, point A must lie between C and K_1 (the addendum circle of the wheel 2, C_{a2} need to cut the line of action between points C and K_1 , and under no circumstances does not exceed the point K_1). Similarly, C_{a1} addendum circle must cut the action line between points C and K_2 , resulting point E, which in no circumstances, does not exceed the point K_2 .

The conditions to avoid the phenomenon of interference can be written with the relations (3.1).

The basic conditions of interference, are the same ($CA < K_1C$; $CE < K_2C$), but the originality of this new presented method consist in the mode in which it was solved the classical relationship (see the system 3.1) (PETRESCU, 2012), (see the Figure 11).






Figure 11. Line of action (t-t') at an external gearing

$$CA < K_1C \text{ and } CE < K_2C$$

$$CA = K_2A - K_2C = \sqrt{r_{a_2}^2 - r_{b_2}^2} - r_2 \cdot \sin \alpha_0; \quad CA < K_1C \Rightarrow$$

$$\Rightarrow \sqrt{r_{a_2}^2 - r_{b_2}^2} - r_2 \cdot \sin \alpha_0 < r_1 \cdot \sin \alpha_0 \Rightarrow \sqrt{r_{a_2}^2 - r_{b_2}^2} < (r_1 + r_2) \cdot \sin \alpha_0$$

$$\Rightarrow d_{a_2}^2 - d_{b_2}^2 < (d_1 + d_2)^2 \cdot \sin^2 \alpha_0 \Rightarrow$$

$$\Rightarrow m^2 \cdot (z_2 + 2)^2 - m^2 \cdot z_2^2 \cdot \cos^2 \alpha_0 < m^2 \cdot (z_1 + z_2)^2 \cdot \sin^2 \alpha_0 \Rightarrow$$

$$\Rightarrow z_2^2 + 4 \cdot z_2 + 4 - z_2^2 \cdot \cos^2 \alpha_0 < z_1^2 \cdot \sin^2 \alpha_0 + 2 \cdot z_1 \cdot z_2 \cdot \sin^2 \alpha_0 \Rightarrow$$

$$\Rightarrow 4 \cdot z_2 + 4 < z_1^2 \cdot \sin^2 \alpha_0 + 2 \cdot z_1 \cdot z_2 \cdot \sin^2 \alpha_0$$

$$\text{from } CE < K_2C \Rightarrow 4 \cdot z_1 + 4 < z_2^2 \cdot \sin^2 \alpha_0 + 2 \cdot z_1 \cdot z_2 \cdot \sin^2 \alpha_0$$

$$\text{it obtains the system } \begin{cases} 4 \cdot z_2 + 4 < z_1^2 \cdot \sin^2 \alpha_0 + 2 \cdot z_1 \cdot z_2 \cdot \sin^2 \alpha_0 \\ 4 \cdot z_1 + 4 < z_2^2 \cdot \sin^2 \alpha_0 + 2 \cdot z_1 \cdot z_2 \cdot \sin^2 \alpha_0 \end{cases}$$

$$\text{take } i \equiv |i_{12}| = \frac{z_2}{z_1} \Rightarrow z_2 = i \cdot z_1; \text{ result the system}$$

$$\begin{cases} \sin^2 \alpha_0 \cdot (1 + 2 \cdot i) \cdot z_1^2 - 2 \cdot 2 \cdot i \cdot z_1 - 4 > 0 \\ \sin^2 \alpha_0 \cdot (i^2 + 2 \cdot i) \cdot z_1^2 - 2 \cdot 2 \cdot z_1 - 4 > 0 \end{cases} \text{ with the solutions:}$$

$$\begin{cases} z_{1,2} = \frac{2 \cdot i \pm 2 \cdot \sqrt{i^2 + \sin^2 \alpha_0 + 2 \cdot i \cdot \sin^2 \alpha_0}}{(2 \cdot i + 1) \cdot \sin^2 \alpha_0} \\ z_{1,3,4} = \frac{2 \pm 2 \cdot \sqrt{1 + i^2 \cdot \sin^2 \alpha_0 + 2 \cdot i \cdot \sin^2 \alpha_0}}{(2 \cdot i + i^2) \cdot \sin^2 \alpha_0} \end{cases} \text{ it keeps solutions +} \tag{3.1}$$

$$\begin{cases} z_{1_2} = 2 \cdot \frac{i + \sqrt{i^2 + \sin^2 \alpha_0 + 2 \cdot i \cdot \sin^2 \alpha_0}}{(2 \cdot i + 1) \cdot \sin^2 \alpha_0} \\ z_{1_4} = 2 \cdot \frac{1 + \sqrt{1 + i^2 \cdot \sin^2 \alpha_0 + 2 \cdot i \cdot \sin^2 \alpha_0}}{(2 \cdot i + i^2) \cdot \sin^2 \alpha_0} \end{cases}$$

Relationship which generates z_{1_4} always gives lower values than the relationship which generates z_{1_2} so it is sufficient the condition (3.2) for finding the minimum number of teeth of the wheel 1, necessary to avoid interference (PETRESCU, 2012).

$$z_{\min} \equiv z_{1_2} = 2 \cdot \frac{i + \sqrt{i^2 + \sin^2 \alpha_0 + 2 \cdot i \cdot \sin^2 \alpha_0}}{(2 \cdot i + 1) \cdot \sin^2 \alpha_0} \tag{3.2}$$



When we have inclined teeth, one takes $z_{\min} \rightarrow z_{\min}/\cos\beta$, and $\alpha_0 \rightarrow \alpha_{0t}$, and the relationship (3.2) takes the form (3.3). The minimum number of teeth of the driving wheel 1, is a function on some parameters: the pressure angle (normal on the pitch circle, α_0), the tooth inclination angle (β), and the transmission ratio ($i=|i_{12}|=|z_2/z_1|=z_2/z_1$), (see the relationship 3.3, and (MAROŞ, 1958); STOICA, 1977).

$$\left\{ \begin{array}{l} z_{\min} \equiv z_{1_2} = 2 \cdot \cos \beta \cdot \frac{i + \sqrt{i^2 + \sin^2 \alpha_{0t} + 2 \cdot i \cdot \sin^2 \alpha_{0t}}}{(2 \cdot i + 1) \cdot \sin^2 \alpha_{0t}} \\ \text{where: } \operatorname{tg} \alpha_{0t} = \frac{\operatorname{tg} \alpha_0}{\cos \beta} \Rightarrow \\ \Rightarrow \alpha_{0t} = \operatorname{arctg} \left(\frac{\operatorname{tg} \alpha_0}{\cos \beta} \right) \end{array} \right. \quad (3.3)$$

The system (3.3) is a simple, unitar and general relationship which can give the solutions of the minimum number of teeth of the wheel 1 (the driving wheel), to avoid the interference. In the following tables (1-15) is chosen an α_0 value (35 [deg]), and successively increased beta angle values (from 0 [deg] to 40 [deg]) and the transmission ratio i (from 1, to 80), and one gets the minimum numbers of teeth. Then, we will decrease successively the value of the angle α_0 (from 35 [deg] to 5 [deg]). See the tables (1-15).

At the internal gearing the condition to avoid the interference is the same like at the external gearing (relation 3.3).

In addition it can write and the condition of the existence of the wheel with the internal teeth (systems 3.4 and 3.5).

$$\left\{ \begin{array}{l} r_{a_2} > r_{b_2} \Rightarrow \frac{m}{2} \cdot \left(\frac{z_2}{\cos \beta} - 2 \right) > \frac{m}{2} \cdot \frac{z_2}{\cos \beta} \cdot \cos \alpha_{0t} \Rightarrow \\ \Rightarrow \frac{z_2}{\cos \beta} - 2 > \frac{z_2}{\cos \beta} \cdot \cos \alpha_{0t} \Rightarrow z_2 > \frac{2 \cdot \cos \beta}{1 - \cos \alpha_{0t}} \end{array} \right. \quad (3.4)$$

$$\left\{ \begin{aligned}
 z_2 &> \frac{2 \cdot \cos \beta}{1 - \cos \alpha_{0t}} \\
 \cos \alpha_{0t} &= \frac{1}{\sqrt{1 + \operatorname{tg}^2 \alpha_{0t}}} = \frac{1}{\sqrt{1 + \frac{\operatorname{tg}^2 \alpha_0}{\cos^2 \beta}}} = \frac{\cos \beta}{\sqrt{\cos^2 \beta + \operatorname{tg}^2 \alpha_0}} \\
 \Rightarrow z_2 &> \frac{2 \cdot \cos \beta}{1 - \frac{\cos \beta}{\sqrt{\cos^2 \beta + \operatorname{tg}^2 \alpha_0}}} \Rightarrow z_2 > \frac{2 \cdot \cos \beta \cdot \sqrt{\cos^2 \beta + \operatorname{tg}^2 \alpha_0}}{\sqrt{\cos^2 \beta + \operatorname{tg}^2 \alpha_0} - \cos \beta} \Rightarrow \\
 \Rightarrow z_2 &> \frac{2 \cdot \cos \beta \cdot \sqrt{\cos^2 \beta + \operatorname{tg}^2 \alpha_0} \cdot (\sqrt{\cos^2 \beta + \operatorname{tg}^2 \alpha_0} + \cos \beta)}{\operatorname{tg}^2 \alpha_0} \Rightarrow \\
 \Rightarrow z_2 &> \frac{2 \cdot \cos \beta}{\operatorname{tg}^2 \alpha_0} \cdot (\cos^2 \beta + \operatorname{tg}^2 \alpha_0 + \cos \beta \cdot \sqrt{\cos^2 \beta + \operatorname{tg}^2 \alpha_0}) \Rightarrow \\
 \Rightarrow z_2 &> \frac{2 \cdot \cos^3 \beta}{\operatorname{tg}^2 \alpha_0} \cdot \left(1 + \frac{\operatorname{tg}^2 \alpha_0}{\cos^2 \beta} + \sqrt{1 + \frac{\operatorname{tg}^2 \alpha_0}{\cos^2 \beta}} \right)
 \end{aligned} \right. \quad (3.5)$$

They were used and additional relations (3.6).

$$\left\{ \begin{aligned}
 r_1 &= \frac{1}{2} m \cdot z_1; \quad r_2 = \frac{1}{2} m \cdot z_2; \quad r_{b_1} = \frac{1}{2} m \cdot z_1 \cdot \cos \alpha_0; \quad r_{b_2} = \frac{1}{2} m \cdot z_2 \cdot \cos \alpha_0 \\
 r_{a_1} &= r_1 + m = \frac{1}{2} m \cdot z_1 + \frac{2}{2} m = \frac{m}{2} \cdot (z_1 + 2) \\
 r_{a_2} &= r_2 - m = \frac{1}{2} m \cdot z_2 - \frac{2}{2} m = \frac{m}{2} \cdot (z_2 - 2) \\
 r_{r_1} &= r_1 - 1.25m = \frac{1}{2} m \cdot z_1 - \frac{2.5}{2} m = \frac{m}{2} \cdot (z_1 - 2.5) \\
 r_{r_2} &= r_2 + 1.25m = \frac{1}{2} m \cdot z_2 + \frac{2.5}{2} m = \frac{m}{2} \cdot (z_2 + 2.5)
 \end{aligned} \right. \quad (3.6)$$

Table 1 $\alpha_0=35$ [deg], $\beta=0$ [deg]



α_0 [deg]	35									
	β [deg]									
	0									
i	1	1.25	1.6	2	2.5	3.15	4	5	6.3	8
Z_{min}	4.8828	5.0325	5.1896	5.3204	5.4386	5.5467	5.6431	5.7198	5.7867	5.8439
i	10	12.5	16	20	25	31.5	40	50	63	80
Z_{min}	5.8880	5.9243	5.9568	5.9805	5.9997	6.0158	6.0290	6.0389	6.0471	6.0539

Table 2 $\alpha_0=35$ [deg], $\beta=10$ [deg]

α_0 [deg]	35									
	β [deg]									
	10									
i	1	1.25	1.6	2	2.5	3.15	4	5	6.3	8
Z_{min}	4.7254	4.8679	5.0174	5.1419	5.2545	5.3576	5.4495	5.5226	5.5865	5.6411
i	10	12.5	16	20	25	31.5	40	50	63	80
Z_{min}	5.6832	5.7178	5.7489	5.7715	5.7898	5.8052	5.8178	5.8273	5.8351	5.8416

Table 3 $\alpha_0=35$ [deg], $\beta=20$ [deg]

α_0 [deg]	35									
	β [deg]									
	20									
i	1	1.25	1.6	2	2.5	3.15	4	5	6.3	8
Z_{min}	4.2799	4.4022	4.5307	4.6379	4.7351	4.8240	4.9035	4.9667	5.0219	5.0693
i	10	12.5	16	20	25	31.5	40	50	63	80
Z_{min}	5.1058	5.1358	5.1627	5.1824	5.1983	5.2116	5.2226	5.2308	5.2376	5.2432



Table 4 $\alpha_0=35$ [deg], $\beta=30$ [deg]

α_0 [deg]	35		β [deg]	30						
i	1	1.25	1.6	2	2.5	3.15	4	5	6.3	8
Z_{min}	3.6198	3.7136	3.8123	3.8949	3.9699	4.0388	4.1004	4.1495	4.1925	4.2294
i	10	12.5	16	20	25	31.5	40	50	63	80
Z_{min}	4.2578	4.2812	4.3022	4.3176	4.3300	4.3404	4.3490	4.3554	4.3608	4.3651

Table 5 $\alpha_0=35$ [deg], $\beta=40$ [deg]

α_0 [deg]	35		β [deg]	40						
i	1	1.25	1.6	2	2.5	3.15	4	5	6.3	8
Z_{min}	2.8475	2.9104	2.9769	3.0327	3.0836	3.1304	3.1724	3.2060	3.2355	3.2608
i	10	12.5	16	20	25	31.5	40	50	63	80
Z_{min}	3.2804	3.2965	3.3110	3.3216	3.3302	3.3374	3.3433	3.3477	3.3514	3.3545

Table 6 $\alpha_0=20$ [deg], $\beta=0$ [deg]

α_0 [deg]	20		β [deg]	0						
i	1	1.25	1.6	2	2.5	3.15	4	5	6.3	8
Z_{min}	12.323	12.966	13.624	14.161	14.637	15.066	15.443	15.740	15.997	16.215
i	10	12.5	16	20	25	31.5	40	50	63	80
Z_{min}	16.382	16.519	16.641	16.730	16.802	16.862	16.911	16.948	16.978	17.003



Table 7 $\alpha_0=20$ [deg], $\beta=10$ [deg]

α_0 [deg]	20									
	β [deg]									
	10									
i	1	1.25	1.6	2	2.5	3.15	4	5	6.3	8
Z_{min}	11.835	12.447	13.075	13.586	14.041	14.450	14.810	15.094	15.339	15.547
i	10	12.5	16	20	25	31.5	40	50	63	80
Z_{min}	15.706	15.837	15.954	16.039	16.107	16.164	16.211	16.246	16.275	16.299

Table 8 $\alpha_0=20$ [deg], $\beta=20$ [deg]

α_0 [deg]	20									
	β [deg]									
	20									
i	1	1.25	1.6	2	2.5	3.15	4	5	6.3	8
Z_{min}	10.446	10.994	11.535	11.977	12.370	12.725	13.036	13.282	13.495	13.676
i	10	12.5	16	20	25	31.5	40	50	63	80
Z_{min}	13.814	13.927	14.028	14.102	14.161	14.211	14.252	14.282	14.308	14.328

Table 9 $\alpha_0=20$ [deg], $\beta=30$ [deg]

α_0 [deg]	20									
	β [deg]									
	30									
i	1	1.25	1.6	2	2.5	3.15	4	5	6.3	8
Z_{min}	8.4777	8.8841	9.3024	9.6448	9.9497	10.225	10.468	10.659	10.825	10.966
i	10	12.5	16	20	25	31.5	40	50	63	80
Z_{min}	11.074	11.163	11.242	11.299	11.346	11.385	11.417	11.441	11.461	11.477



Table 10 $\alpha_0=20$ [deg], $\beta=40$ [deg]

α_0 [deg]	20		β [deg]	40							
i	1	1.25	1.6	2	2.5	3.15	4	5	6.3	8	
Z_{min}	6.2280	6.5020	6.7854	7.0182	7.2263	7.4147	7.5813	7.7128	7.8269	7.9241	
i	10	12.5	16	20	25	31.5	40	50	63	80	
Z_{min}	7.9985	8.0597	8.1143	8.1540	8.1862	8.2131	8.2352	8.2517	8.2654	8.2767	

Table 11 $\alpha_0=5$ [deg], $\beta=0$ [deg]

α_0 [deg]	5		β [deg]	0							
i	1	1.25	1.6	2	2.5	3.15	4	5	6.3	8	
Z_{min}	176.52	188.86	201.22	211.13	219.81	227.54	234.28	239.55	244.09	247.93	
i	10	12.5	16	20	25	31.5	40	50	63	80	
Z_{min}	250.85	253.24	255.37	256.92	258.17	259.21	260.06	260.70	261.23	261.67	

Table 12 $\alpha_0=5$ [deg], $\beta=10$ [deg]

α_0 [deg]	5		β [deg]	10							
i	1	1.25	1.6	2	2.5	3.15	4	5	6.3	8	
Z_{min}	168.66	180.45	192.25	201.72	210.01	217.38	223.83	228.86	233.19	236.86	
i	10	12.5	16	20	25	31.5	40	50	63	80	
Z_{min}	239.65	241.94	243.97	245.45	246.64	247.63	248.45	249.06	249.57	249.98	



Table 13 $\alpha_0=5$ [deg], $\beta=20$ [deg]

α_0 [deg]	5									
	β [deg]									
	20									
i	1	1.25	1.6	2	2.5	3.15	4	5	6.3	8
Z_{min}	146.73	156.95	167.20	175.42	182.62	189.03	194.63	198.99	202.76	205.94
i	10	12.5	16	20	25	31.5	40	50	63	80
Z_{min}	208.37	210.35	212.12	213.40	214.44	215.30	216.01	216.54	216.98	217.34

Table 14 $\alpha_0=5$ [deg], $\beta=30$ [deg]

α_0 [deg]	5									
	β [deg]									
	30									
i	1	1.25	1.6	2	2.5	3.15	4	5	6.3	8
Z_{min}	115.16	123.15	131.16	137.58	143.22	148.23	152.61	156.03	158.97	161.47
i	10	12.5	16	20	25	31.5	40	50	63	80
Z_{min}	163.37	164.92	166.30	167.31	168.12	168.79	169.35	169.76	170.11	170.39

Table 15 $\alpha_0=5$ [deg], $\beta=40$ [deg]

α_0 [deg]	5									
	β [deg]									
	40									
i	1	1.25	1.6	2	2.5	3.15	4	5	6.3	8
Z_{min}	80.086	85.602	91.136	95.575	99.465	102.93	105.96	108.33	110.36	112.09
i	10	12.5	16	20	25	31.5	40	50	63	80
Z_{min}	113.40	114.48	115.43	116.13	116.69	117.16	117.54	117.83	118.07	118.26



The presented method has the great advantage to optimize the number of teeth for a gear before to make its synthesis. In this mode the constructor may elect the minimum number of teeth, for an imposed transmission ratio, i .

Classical to realize an $i=2$, the constructor can select between 18 or 33 teeth to the driving wheel 1, which means a 36 or 66 teeth for the driven wheel 2. With the aid of the presented tables, he can make a multiple selection.

The engineer can select for the driving wheel 1 a number of teeth $z_1=6$, with an $\alpha_0=35$ [deg], and a $\beta=0$ [deg]. He may do this not only for a transmission ratio $i=2$, but and for the domain from $i=1.25$ to $i=25$ (see the table 1).

If he elect $\alpha_0=35$ [deg] and $\beta=40$ [deg], then he can take a number of teeth for the driving wheel 1 of $z_1=4$, and can do this for the entire domain from $i=2$ to $i=80$ (see the table 5). The constructor may do this when it is necessary a minimum number of teeth, but with an efficiency of the gear decreasing.

Contrary, when we wish a great efficiency, one must increase the number of teeth and decrease the angles α_0 and β . With an $\alpha_0=5$ [deg] and $\beta=0$ (table 11), we can take the number of teeth at the driving wheel 1, from $z_1=189$ (for $i=1.25$), to $z_1=262$ (for $i=80$).

For the known classical $\alpha_0=20$ [deg] and $\beta=0$ [deg], when the ratio i vary from 1 to 80, z_1 takes the values from 13 to 18 (see the table 6). With the classical method it was taken only the minimum value 18 to the minimum number of teeth (PETRESCU, 2012).

4. CONCLUSIONS

The presented method manages to synthesize (in theory) the best option parameters for any desired gear.

Relationships shown have the great advantage of donating optimal solutions for any situation you want without the need for difficult calculations, experimental building, or specialized software. All relationships have been calculated and checked with programs written in excel.

Comparisons made with specialized software (Inventor) showed a precision (matching) perfect. Workload and procedures could be so much smaller.



The parallel drawn between the software "Autodesk Inventor" and the presented calculation relationships will be highlighted in the following paper (as handle a large volume), (OLIVEIRA; LIMA, 2003).

Applied in the automotive industry, at the transmission mechanisms, these changes may decrease overall fuel consumption further, and pollutant emissions (NOGUEIRA; REAL, 2011).

Gears can be designed to operate without noise (PELECUDI et al., 1985), (PETRESCU; PETRESCU; POPESCU, 2007; MAROȘ, 1958), (LENI MATOS, 2011; NOGUEIRA; REAL, 2011).

But, the applications will be spectacular in the automatic transmissions used in aerospace, in robotics and mechatronics.

When the number of teeth of the wheel 1 increases, it can decrease the normal pressure angle, α_0 . One shall see that for $z_1=90$ it can take less for the normal pressure angle (for the pressure angle of reference), $\alpha_0=8^\circ$.

The efficiency (of the gear) increases when the number of teeth for the driving wheel 1, z_1 , increases as well, and when the pressure angle, α_0 , diminishes; z_2 or i_{12} are not so much influence about the efficiency value;

It can easily see that for the value $\alpha_0=20^\circ$, the efficiency takes roughly the value $\eta\approx 0.89$ for any values of the others parameters (this justifies the choice of this value, $\alpha_0=20^\circ$, for the standard pressure angle of reference).

The better efficiency may be obtained only for a $\alpha_0\neq 20^\circ$.

But the pressure angle of reference, α_0 , can be decreased the same time the number of teeth for the driving wheel 1, z_1 , increases, to increase the gears' efficiency;

Contrary, when we desire to create a gear with a low z_1 (for a less gauge), it will be necessary to increase the α_0 value, for maintaining a positive value for α_m (in this case the gear efficiency will be diminished);

When β increases, the efficiency, η , increases too, but the growth is insignificant.

The module of the gear, m , has not any influence on the gear's efficiency value.

When α_0 is diminished it can take a higher normal module, for increasing the addendum of teeth, but the increase of the module m at the same time with the increase of the z_1 can lead to a greater gauge.



The gears' efficiency, η , is really a function of α_0 and z_1 : $\eta=f(\alpha_0, z_1)$; α_m and α_M are just the intermediate parameters.

For a good projection of the gear, it's necessary a z_1 and a z_2 greater than 30-60; but this condition may increase the gauge of mechanism.

The best efficiency can be obtained with the internal gearing when the drive wheel 1 is the ring; the minimum efficiency will be obtained when the drive wheel 1 of the internal gearing has external teeth.

For the external gearing, the best efficiency is obtained when the bigger wheel is the drive wheel; when we decrease the normal angle α_0 , the contact ratio increases and the efficiency increases as well.

The efficiency increases too, when the number of teeth of the drive wheel 1 increases (when z_1 increases).

Optimizing this mechanism (the gears mechanism), we can improve the functionality of the transmissions with gears.

At the gear mechanisms an important problem is the interference of the teeth. To avoid the interference between teeth, we must know the minimum number of teeth of the driving wheel, in function of the pressure angle (normal on the pitch circle, α_0), in function of the tooth inclination angle (β), and in function of the transmission ratio (i).

REFERENCES

LEI X., A. O. (2011), Design and Analysis for High-speed Gear Coupling, **Applied Mechanics and Materials journal**, v. 86, p. 658-661.

LIN C., A. O. (2011), The Design and Experiments of Oval Bevel Gear, **Applied Mechanics and Materials journal**, v. 86, p. 297-300.

MAROȘ, D. (1958), **Cinematica roților dințate**. Editura Tehnică, București.

LENI MATOS, B. M. (2011), A Comparison of the Delay Spread Obtained with Different Power Delay Profiles De-Noising Techniques, **ENGEVISTA**, v. 13, n. 2, p. 129-133. Available on:

<http://www.uff.br/engevista/seer/index.php/engevista/article/view/280>

NOGUEIRA, O. C.; REAL, M. V. (2011), Estudo Comparativo De Motores Diesel Maritimos Atraves Da Analise De Lubrificantes Usados e Engeharia De Confiabilidade, **ENGEVISTA**, v. 13, n. 3, p. 244-254. Available on:

<http://www.uff.br/engevista/seer/index.php/engevista/article/view/300>



OLIVEIRA, M. M. P.; LIMA, F. R. (2003), Analogias Entre o Desenho Instrumental e o Desenho Computacional, in **ENGEVISTA**, v.5, n. 2, Available on: <http://www.uff.br/engevista/seer/index.php/engevista/article/view/108>

PELECUDI, C. H. R.; MAROS, D.; MERTICARU, V.; PANDREA, N.; SIMIONESCU, I. (1985), **Mecanisme**. E.D.P., București.

PETRESCU, V.; PETRESCU, I. (2002), **Randamentul cuplei superioare de la angrenajele cu roți dințate cu axe fixe**, In: The Proceedings of 7th National Symposium PRASIC, Brașov, v. I, p. 333-338.

PETRESCU, R.; PETRESCU, F. (2003), **The gear synthesis with the best efficiency**, In: The Proceedings of ESFA'03, Bucharest, v. 2, p. 63-70.

PETRESCU R. V.; PETRESCU F. I.; POPESCU N. (2007), **Determining Gear Efficiency**, In Gear Solutions magazine, USA, p. 19-28, March. Available on: <http://www.gearsolutions.com/media/uploads/assets/PDF/Magazines/GearSolutions0307.pdf>

PETRESCU, F. I. (2012), **Teoria mecanismelor – Curs si aplicatii** (editia a doua), Create Space publisher, USA, September, ISBN 978-1-4792-9362-9, 284 pages, Romanian version. Available on: <http://www.amazon.com/Teoria-Mecanismelor-Curs-aplicatii-Romanian/dp/1479293628>

REY G. G. (2013), Influencia de la lubricacion en la eficiencia de engranajes de tornillo sinfin, **Ingenieria Mecanica journal**, ISSN 1815-5944, v. 16, n. 1, p. 13-21. Available on: <http://www.redalyc.org/articulo.oa?id=225125743002>

STOICA, I. A. (1977), **Interferența roților dințate**. Editura DACIA, Cluj-Napoca.

